


0




1



2




3




BAND: 5 cm

4




HALVE BAND: 2.5 cm

5




HALVE AGAIN: 1.25 cm


6




7




8



9




10




ROOT: 1.5 cm FROM CENTER

11




12




ROOT: 1.5 cm FROM CENTER

13




14




WING: 10° ABOVE LEVEL

15




WING: 10° ABOVE LEVEL

16




TIP STRIP: ⅛ in

17




TIP STRIP: ⅛ in

18




RAISE TAB: 10° STARTING SETTING

19




RAISE TAB: 10° STARTING SETTING


20



21



22



ADJUST GRADUALLY · NO GUARANTEED RETURN